



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com
Web Site: www.radiantwraps.com

SNIPPING END OF BACK PANEL



#1 – Back panel extends in to or is flush against an intersecting wall. Use shim to create space off the back wall.



#2 – Use metal snips to slice top rail first. Be careful of sharp edges.



#3 – Carefully snip out $\frac{1}{4}$ " to $\frac{1}{2}$ " of back panel from top to bottom or use open end caps that require a smaller notch.



#4 – Snip out entire end section of back panel to accept new end cap or use open end caps that require a smaller notch.



#5 – Install new panel and end cap.