



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com
Web Site: www.radiantwraps.com

INSTALLING FLASHING, WIRE SUPPORTS & MOUNTING BRACKETS FOR INSTALLATIONS WHERE THE BACK PANEL IS MISSING OR HAS BEEN REMOVED



#1 –The original baseboard enclosures have been removed (see *Removing Back Panel* page for detail).



#2 – A 6-inch high coil of tin roof flashing should be rolled out and cut to cover the wall area. Paint the silver flashing with a flat black paint (Rustoleum).



#3 – The painted tin flashing is slipped down along the wall to the floor and secured with staples, tacks, or roofing nails.



#4 – A hook & eye screw, & wire support should be installed at 6" off the floor every 3 to 4 feet. (See Hook & Eye Support for detail).



#5 – The mounting brackets are installed (see *Mounting Bracket Installation* page for more detail).



#6 – The panels are then slipped into place so that the back flange slides down into the mounting bracket channel.