



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com
Web Site: www.radiantwraps.com

MOUNTING BRACKET INSTALLATION



#1 – Mounting brackets used for install when back panel of enclosure is missing.



#2 – Position panel and lightly mark height of top rail on the wall. Tip panel forward and mark the location of the back teeth.



#3 – Position mounting bracket 1/8" below top line and in between teeth. Pre-drill and install plastic anchors when there's no stud.



#4 – Install mounting brackets. You may have to use a small pry bar to widen the gap off the wall at the top of the bracket.



#5 – Install two mounting brackets for each panel.



#6 – Slide back flange of new panel down into mounting brackets.