



134 Sand Park Road
Cedar Grove, NJ 07009
Phone: 973 857-6480 Fax: 973 857-4943
E-Mail: Sales@radiantwraps.com
Web Site: www.radiantwraps.com

RE-USING EXISTING SUPPORT BRACKETS
FOR INSTALLATIONS WHERE BACK PANEL HAS BEEN REMOVED



#1 – Refer to *Removing Existing Back Panels & Support Brackets* page for preparation. Snip off support brackets at appropriate height as determined by Radiant Wraps.



#2 – In the event that the pre-drilled holes have been snipped off, re-drill a hole for re-mounting the support bracket to the wall.



#3 – Slide support bracket into place and prepare starter hole for screw mounting.



#4 – Level off heating element and install screw to anchor support bracket to wall.



#5 – This photo shows support brackets re-attached.



#6 – This photo shows the heating element and support brackets re-installed after removal of the back panel.